

HEADLIGHT REPAIR PROCESS

TIME FOR REPAIR: 15 MINUTES (NOT INCLUDING MOUNTING/ASSEMBLY)



STEP 1 SANDING



TAPE OFF THE HEADLIGHT WITH **NORTON ORANGE TAPE**



DRY SAND WITH **NORTON PRO PLUS SMART REPAIR A975 DISC P500**



DRY SAND WITH **NORTON SUPERFLEXIBLE Q775 DISC P800 + SOFT INTERFACE**



WIPE WITH **NORTON BLUE MAGNET MICROFIBRE CLOTH**



WET SAND WITH **NORTON SUPERFLEXIBLE Q775 DISC P1500 + SOFT INTERFACE**



WET SAND WITH **NORTON SUPERFLEXIBLE Q775 DISC P3000 + SOFT INTERFACE**



CLEAN THE SURFACE WITH **NORTON BLUE MAGNET MICROFIBRE CLOTH**



STEP 2 POLISHING



POLISH WITH **FARÉCLA G360 SUPER FAST COMPOUND + FARÉCLA YELLOW G MOP**



WIPE THE SURFACE WITH **NORTON BLUE MAGNET MICROFIBRE CLOTH**



CLEAN THE AREA AROUND THE HEADLIGHT WITH **NORTON LIQUID ICE DETAILER SPRAY**



WIPE THE SURFACE WITH **NORTON BLUE MAGNET MICROFIBRE CLOTH**



APPLY **FARÉCLA G3 WAX PREMIUM + FARÉCLA G PRO APPLICATOR WAFFLE PAD BLACK**
[use the white pad with G360 after washing the car if you see some scratches]



WIPE WITH **NEW CLEAN BLUE MAGNET MICROFIBRE CLOTH**



SCAN TO WATCH



NORTON HEADLIGHT REPAIR KIT
ART. NO 78072769407